



**1** 1181 x 394mm



**2** 1181 x 394mm




**3** 1190 x 233mm (2x)



**4** 400 x 230mm (2x)



**5** 500 x 398mm




**6** 459 x 45mm (4x)



**7** 459 x 388mm




**8** 420 x 338mm (6x)



**9** 453 x 190mm (6x)




**10** 340 x 115mm (6x)





**11** 340 x 115mm (6x)





**12** 407 x 115mm (6x)


A x 48  Ø8x30mm


H x 30 


B x 49  Ø3,0x12mm


J x 1  1164mm


C x 69  Ø4,0x30mm


K x 1 


D x 24  Ø6,0x10mm


L x 2 



E x 6  Ø7,0x35mm



M x 6  a  
b

F x 1 




N x 6  a  
b

G x 1 









3






4





**5**






**6**



7

|   |   |
|---|---|
| Hx30  | Jx1   |
|  |  |



## WARNING






Serious or fatal injuries can occur from furniture tipping over. To prevent the furniture from tipping over we recommend that it is permanently fixed to the wall.






Wall anchor and hardware are included with this product.

Please make sure hardware is suitable for your walls before installing, as different wall materials may require different types of anchors.

Drill your wall with a 6mm drill (not included) and insert hardware (F), securing wall anchor (K) with washer (L) and screw (C) in the wall.


Attach screw (B) into washer (L), securing wall anchor (K) at the under middle part (5).




| Bx1  | Cx1   | Fx1   | Kx1   | Lx2   |
|--|---|---|---|---|
|  |  |  |  |  |
| Ø3,0x12mm  | Ø4,0x30mm   |   |   |   |





9



The side drawer with WARNING LABEL, should be mounted in highest drawer.







6x



10

6x

| Bx24      | Mx6 | Nx6 |
|-----------|-----|-----|
|           |     |     |
| Ø3,0x12mm | b   | b   |




11

The side drawer with the WARNING LABEL, should be mounted in highest drawer.

**▲ WARNING**  
Children have died from furniture tipover. To reduce the risk of furniture tipover:


- ALWAYS install tipover restraint provided.
- NEVER put a TV on this product.
- NEVER allow children to stand, climb or hang on drawers, doors, or shelves.
- NEVER open more than one drawer at a time.
- Place heaviest items in the lowest drawers.

*This is a permanent label. Do not remove!*




12


Bx24




a:



b:





**GENERAL CARE & MAINTENANCE**

We advise that when cleaning the product that a damp cloth is used.

Avoid the use of all household cleaners and abrasive.

Never push or drag the furniture.

Never attempt to move the furniture when fully loaded.

We advise that periodically all fixing are re-tightened.